

# NO-COAT WOOD INSTALLATION INSTRUCTIONS

## IDENTIFYING PARTS



## INSTALLATION

1. Prepare the subfloor according to the manufacturer's instructions.

2. Lay the planks in a staggered pattern, starting from the wall.

## FINISHING

1. Apply the finish to the top surface of the planks.
2. Allow the finish to dry completely before walking on the floor.
3. Clean up any excess finish immediately.
4. Avoid using harsh cleaning products on the finished floor.
5. Reapply the finish as needed to maintain the appearance of the floor.

