

NO-CURT Series INSTALLATION INSTRUCTIONS

STEP 1: VERIFY DIMENSIONS



WARNING:
This window blind is designed for use on windows with a maximum width of 48 inches. For windows wider than 48 inches, please contact our customer service department for additional information. Do not attempt to install this blind on a window wider than 48 inches, as this may result in damage to the blind or the window frame.



STEP 2: MOUNTING

Part	Description
1	Bracket
2	Screw
3	Blind
4	Washer
5	Spacer
6	Cap Screw

WARNING:
Do not use power tools to install this blind. Use a screwdriver to install the screws. Do not over-tighten the screws, as this may damage the window frame or the blind. The blind should be installed in a window that is free of any obstructions, such as paint or wallpaper. The window frame should be clean and dry before installation.

