

McFIT McFIT

INSTALLATION

INSTRUCTIONS

THE McFIT McFIT



TOOLS REQUIRED

- 1. Allen key
- 2. Screwdriver

WARNING

Do not use the product if you are unable to follow the instructions.

INSTALLATION

1. Remove the top cover.
2. Insert the screws into the top cover.
3. Tighten the screws.
4. Insert the nuts into the top cover.
5. Tighten the nuts.
6. Insert the top cover into the base.
7. Tighten the top cover.

