

# NO-CURT Series INSTALLATION INSTRUCTIONS

## IDENTIFY PARTS



## PREPARATION

1. Measure the window opening.
2. Determine the mounting height.
3. Mark the mounting points.
4. Drill the mounting holes.
5. Install the mounting brackets.
6. Attach the top rail.
7. Attach the bottom rail.
8. Thread the cord through the top rail.
9. Attach the cord lock.
10. Attach the cord cleat.
11. Attach the cord hook.
12. Attach the cord stop.
13. Attach the cord end cap.

