

# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## APPLICATIONS

Make	Model
Buick	Terraza
Chevrolet	Uplander
Pontiac	Montana SV6
Saturn	Relay

## CUSTOM WIRING CONNECTOR



## WIRING LOCATION GUIDE

### SUVs, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

S3 - Behind driver side rear access panel



## NOTICE

All steps must be followed to ensure the wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

Panel trim removal tool

## ⚠ WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

# INSTALLATION / SAFETY INSTRUCTIONS

## Step 1


Open the vehicle tailgate. Remove the threshold trim along the rear doors and the interior trim panel on the driver side (A).

## Step 2

Behind the removed trim panel locate the vehicle taillight wiring harness connectors. The connector will be similar to the connector on the custom wiring harness. If the connector is already connected separate them taking care not to damage the locking tabs.

## Step 3

Insert the custom wiring harness end between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place (C).

 **WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

## Step 5

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

## Step 6

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.

