



X-ACT CONTOUR FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN:52731

Thank you for selecting an X-act Contour™ Floor Liners from Husky Liners Inc. Your new liners are custom molded to fit your specific vehicle's floor board. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



LEFT OR DRIVER'S SIDE



RIGHT OR PASSENGER'S SIDE

TO EASE INSTALLATION OF YOUR NEW FRONT LINERS, MOVE BOTH FRONT SEATS TO THE MOST REARWARD POSITION. WITH THIS DONE, INSTALL LINERS AS SHOWN IN THE IMAGES ABOVE. THE DRIVER'S SIDE LINER WILL ATTACH TO THE FACTORY FLOOR MAT RETAINING POSTS LOCATED IN THE FACTORY CARPETING. IF YOUR TRUCK HAS A MANUAL TRANSFER CASE SHIFTER, PLEASE REFER TO THE BACK OF THIS PAGE FOR TRIM INSTRUCTIONS.

TO TRIM FOR A MANUAL TRANSFER CASE SHIFTER, USE THE MOLDED IN TRIM GROOVE IN THE LINER AS YOUR TRIMMING GUIDE AND REMOVE THE SECTION OF THE LINER THAT MATCHES UP TO THE TRANSFER CASE SHIFTER HOUSING. A UTILITY KNIFE OR HEAVY SCISSORS TO REMOVE THIS SECTION OF LINER.

