



X-ACT CONTOUR® FLOOR LINERS

PT #5556

CARE AND USE INSTRUCTIONS

Thank you for selecting an X-act Contour® Floor Liner from Husky Liners. Your new third seat liner is custom molded to fit your vehicle. The liner is made to take the place of your factory floor mats. ***For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner.*** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

INSTALLATION INSTRUCTIONS FOR YOUR X-ACT CONTOUR THIRD SEAT FLOOR LINER



TO INSTALL YOUR LINER, FLIP & SLIDE FORWARD THE 2ND ROW SEATS TO EXPOSE THE 3RD ROW FLOOR PAN. THEN, INSTALL YOUR LINER, POSITIONING IT AS SHOWN ABOVE. LASTLY, REPOSITION THE 2ND ROW SEATS. THE FRONT EDGE OF THE 3RD SEAT LINER TUCKS BEHIND THE REAR WALL OF THE 2ND SEAT LINER.

IF YOUR VEHICLE IS EQUIPPED WITH 2ND ROW BUCKET SEATING WITH THE OPTIONAL CONSOLE OR 2ND ROW BENCH SEATING, YOU WILL NEED TO TRIM YOUR 3RD SEAT FLOOR LINER TO ACHIEVE THE PROPER FIT. PLEASE REVIEW THE BACK OF THIS PAGE FOR MORE INFORMATION.



X-ACT CONTOUR® FLOOR LINERS

PT #5556

FOR MODELS WITH 2ND ROW BUCKETS WITH THE OPTIONAL 2ND ROW CONSOLE: REMOVE THE SECTION OF THE LINER SHOWN BELOW USING THE MOLDED IN TRIM TROUGH. A UTILITY KNIFE OR HEAVY SHEARS WORK WELL FOR TRIMMING.





X-ACT CONTOUR® FLOOR LINERS

PT #5556

MODELS WITH 2ND ROW BENCH SEATS: FOLLOW THE TRIM STEP ALL THE WAY ALONG THE RAISED RIB AS SHOWN BELOW. A UTILITY KNIFE OR SHEARS WORK WELL FOR TRIMMING.

