

WeatherTech®

Tailgate TechLiner™ Installation Instructions

Thank you for purchasing your WeatherTech® Tailgate TechLiner™. The Tailgate TechLiner™ will offer incredible, affordable protection and years of reliable use if you follow these simple instructions.



Parts Kit # 88TG04
(1) T-30 1/4" Insert Bit
(6) Plastic Shoulder Washers



Tools required
1/4" Drive Socket Set or
1/4" Wrench



1 Lower the tailgate and remove all tailgate accessories prior to installation. Clean your truck bed and tailgate with soap and water or TechCare™ Gentle Car™ Shampoo and dry thoroughly before installing the Tailgate TechLiner™.



2 Unroll your Tailgate TechLiner™ and lay out to allow liner to flatten on a dry, flat surface. (For faster results, lay liner in the sun and put a small weight on each of the corners.)

**Take note of the location of the Velcro® pads on the back of the Tailgate TechLiner™, and prevent pads from becoming dirty or collecting debris. Do not remove the adhesive backing at this time.*



3 While the Tailgate TechLiner™ is flattening, use the enclosed Torx bit to remove the 4 bolts from the tailgate as shown.



4 Lay the Tailgate TechLiner™, Velcro® pads facing down, onto the tailgate making certain the features align. Do not remove the plastic backing from the Velcro® at this time.

[View Easy Installation Video](#)

WeatherTech.com/install

Questions? Call customer service at 800 441 6287
Monday - Friday: 9 a.m. to 5 p.m. Central Time

 Proudly Designed,
Engineered and
Manufactured
in the USA

67TG04
© 2012 by MacNeil IP LLC


Specialists in Original Equipment and
Aftermarket Automotive Accessories
1 MacNeil Court • Bolingbrook, IL 60440
800-441-6287 • 630-769-1500 • fax 630-769-0300
WeatherTech.com

WeatherTech®

Tailgate TechLiner™ Installation Instructions



5 Locate the enclosed washers and the 4 bolts you previously removed from the steel panel. Remove the white washers from the bolts and replace them with the black washers provided in the parts kit so the large diameter of the washer goes under the bolt head as shown.

6 Hand tighten all 4 bolts in their original holes first, then tighten each one using the Torx bit. **DO NOT OVER TIGHTEN.**



7 Bend the Tailgate TechLiner™ backward to locate the first Velcro® disc without shifting the position of the Tailgate TechLiner™. Remove the plastic backing from the Velcro® disc and fold the Tailgate TechLiner™ back into place. Press down firmly on the location of the Velcro® disc.

8 Continue this process for each Velcro® disc working your way to the other end. Take care not to pull apart or peel off the Velcro® discs until you affix them to the tailgate.

WARNING!

NOTE: It is imperative to adhere the Tailgate TechLiner™ to the tailgate of the truck as described above. Failure to do so may allow the Tailgate TechLiner™ to lift during travel as a result of turbulent airflow, which could result in unsafe conditions for the operator of the vehicle or other vehicles nearby.

Clean your Tailgate TechLiner™ using mild soap and water, or use our TechCare™ FloorLiner™ & FloorMat Cleaner and Protector for best results.

[View Easy Installation Video](#)

WeatherTech.com/install

Questions? Call customer service at 800 441 6287
Monday - Friday: 9 a.m. to 5 p.m. Central Time



67TG04
© 2012 by MacNeil IP LLC

MacNeil
AUTOMOTIVE
PRODUCTS LIMITED
Specialists in Original Equipment and
Aftermarket Automotive Accessories
1 MacNeil Court • Bolingbrook, IL 60440
800-441-6287 • 630-769-1500 • fax 630-769-0300
WeatherTech.com