

Step 1
Remove the front panel
of the printer.



Step 2
Remove the front panel
of the printer.
Remove the front panel
of the printer.
Remove the front panel
of the printer.

