

4.000 4000 J

Model	Power (kW)	Power (hp)	Speed (km/h)	Max. Torque (kgm)	Max. Torque (Nm)
4.000 4000 J	100	136	180	12,5	117



INSTALLATION



1. ENGINE MOUNTING
The engine is mounted on a frame with a central support and four wheels. The mounting surface is indicated by a horizontal line above the engine.

2. TRANSMISSION MOUNTING
The transmission is mounted on a frame with a central support and four wheels. The mounting surface is indicated by a horizontal line above the transmission.