

# McQuint McQuint

## INSTALLATION

# INSTRUCTIONS

## THE McQuint McQuint INSTALLATION



### SCREW REMOVAL

1. Remove the screws from the top of the unit.

### REMOVAL

1. Remove the unit from the wall by pulling it away from the wall.

### INSTALLATION

1. Mount the unit to the wall using the screws and nuts.
2. Tighten the screws and nuts.
3. Check the unit is level.
4. Check the unit is secure.
5. Check the unit is flush with the wall.
6. Check the unit is not obstructed.
7. Check the unit is not damaged.
8. Check the unit is not overhanging.

