

## CHANGING BATTERIES

Step 1

Remove the back cover by sliding the cover up and then pulling it off the back of the camera.



Step 2

Remove the old battery by pulling it out of the battery compartment.



Step 3

Insert the new battery into the battery compartment.



Step 4

Press the back cover down until it is fully seated.

